SHARP

MODEL:

EM-60PM-WH

PERSONAL BLENDER INSTRUCTION MANUAL



Please read these instruction carefully before operating the appliance.


IMPORTANT SAFEGUARDS

- 1. Read all instructions before use and save for future reference.
- 2. Before using for the first time, remove and safely discard all packing materials and promotional labels.
- 3. The blender is for household use only. Do not use outdoors.
- 4. Before connecting, check that the voltage power corresponds to the one shown on the appliance nameplate.
- 5. Do not let cord hang over edge of table or counter or on hot surface.
- Do not operate any appliance with a damage cord or plug or after the appliance malfunction or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
- 7. If the supply cord is damaged, it must be replaced by the manufacture or its service agent or a similarly quality person in order to avoid a hazard.
- 8. Close supervision is necessary when any appliance is used by or near children.
- 9. Avoid contacting moving parts.
- 10. Blades are sharp, so handle carefully.
- 11. Never use hot liquids or run the appliance empty.
- 12. Only use the accessories provided.
- 13. The appliance can not be used for blending hard and dry substance, otherwise the blade could be blunted. But it can be used for blending ice cube.
- 14. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- 15. To protect against a fire, electric shock or personal injuries, never immerse the blender, motor unit or power cord in water. Do not allow any moisture to come into contact with these parts.
- 16. Be sure blending cover is accurately put in place before operating appliance.
- 17. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
- 18. To reduce the risk of injury, never place cutter-assembly blades on base without jar or bowl properly attached.

- 19. This appliance is not intended for used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- 20. Children should be supervised to ensure that they do not play with the appliance.
- 21. Do not immerse the Motor Unit into water or other liquids.

HOUSEHOLD USE ONLY

KNOW YOUR BLENDER



	With container unit
Power Supply	AC 220-240V 50/60Hz
Power	300W
Rating	Continuious(Repetition of 1-
	minute on, 3-minutes off)
Capacity	600ML
Cutting blades	Stainless steel blades
Product dimension(L X W X H)	145mm X 145mm X 400mm

BEFORE THE FIRST USE

 Check that all parts are complete and not damaged. Clean the attachment according to the section "CLEANING AND MAINTENANCE".

WARNING: The blade is sharp, handle with great care and ensure that the appliance is unplugged from outlet before assembling and removing parts.

2. The correct assembly way will be described in detail in below sections.

Before assembling the bottle, be sure the power cord is unplugged from the power outlet.

For attaching bottle, firstly place the bottle lid into the bottle, ensure the bottle lid is placed tightly and properly with the bottle. And then place the bottle into the motor unit properly.

Note: Make sure all the assembly is placed properly.

Operation of Your Blender

Note: Maximum ingredients volumn is 600ml.

This appliance is provided with an additional portable plastic bottle for your convenient to enjoy different drinks.

- 1. Place the motor unit on the flat surface. Make sure the power outlet is unplugged.
- Place the portable bottle on a flat surface with the open ending facing up. Fill the bottle with your favorite ingredients. Be sure not to fill ingredients exceed the 600ml mark.

Note: For optimal performance, place desired ingredients in the bottle according to the following order: liquids, fresh ingredients, frozen fruit, yogurt and ice cream.

- 3.Please peel or core the fruit or vegetables and then cut it into small dices; Generally the size of fruit or vegetable dices is 15×15×15 mm.
 - Note: Never use boiling liquids or run the appliance empty.
- 4. Assemble the blade assembly onto the opening end of the bottle by turning it in clockwise.
- 5. Upend the assembly of bottle and blade assembly, and insert them into the motor unit, make sure arrow on the motor unit align with the blade assembly, then turn the assembly in clockwise to lock them.
- 6. Connect the plug to wall outlet and the appliance will start operating.

Note: The appliance can be operated without interruption for a maximum of 1 minute, after which it should be allowed to cool down for around 3 minutes.

- 7. When the operation is finished, turn the bottle assembly in anti-clockwise to stop the operation.
- 8. Upend the bottle assembly, hand the bottle with one hand, and turn the cup base in anticlockwise with the other hand to remove it.
- 9. Then assemble the bottle lid on the bottle. Take the bottle with you throughout the day to stay hydrated. When you need to drink, you just need to open the spout lid to serve easily.

Note: After you have consumed your blended beverage, wash out the cup and reuse it throughout the day for water or other cold liquids.

CLEANING AND MAINTENANCE

- -After use, reassemble the bottle and pour a little warm water into it and turn the speed selector to Pulse position for a few seconds to remove the residual food.
- -After stop, remove the bottle from the motor unit and rinse the bottle under running water.
- -Wiping the outer surface of motor unit with a damp cloth, do not use abrasive cleansers. Never immerse in water or other solution for cleaning.
- -Dry all parts and then replace them.

Warning: Do not use abrasive cleansers. Never immerse in water for cleaning.

Note: The blade is very sharp, handle carefully when clean.

ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment! Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.

