


How To Preset



Plug cord to AC outlet.
All the lamps are off, the LED shows as below:



Press the PRESET key, the "PRESET" lamp lights. The LED shows 2 hours firstly and press the PRESET key once, the time add 1 hour until to 14 hours.



Press the RICE COOK key, the "RICE COOK" lamp and "PRESET" lamp light. The preset process has started.



If you want to have porridge, please press the PORRIDGE key, the "PORRIDGE" lamp and "PRESET" lamp light. The preset process has started.



When the time show 1 hour, the "PRESET" lamp will be off, the "RICE COOK" lamp still lights and the cooking process has started. When the time show 2 hour, PORRIDGE cooking process has started. The LED shows as running round.



When the rice or porridge is done, the "KEEP WARM" lamp lights to show that the warmer function is working.



Cautions

- DO NOT use this rice cooker for any purpose other than steaming rice.
- Clean the rice cooker, particularly the steam cap after every use.
- DO NOT clog the holes of steam cap.
- Plug into properly wired wall outlet. Before you plug it in, make sure the voltage of the unit is the same as your local supply.
- DO NOT expose to water, high humidity, or heat sources. Do not use the inner pot directly on an open flame.
- DO NOT cover the lid with a cloth. The lid may deform or change color.
- DO NOT tilt the rice cooker on its edge or place it upside down with its power supply plug connected, as this may cause damaged. When tilting or placing the rice cooker upside down, make sure to disconnect the power supply plug.
- The lid must be closed tightly in the latched position at all times during cooking. (i.e. The unit must not be operated with the lid opened)

How To Clean

- Soak inner pot and inner lid in water and wash with a sponge.
- Wipe body with a damp cloth. Do not immerse in water.
- Do not use abrasive cleaners or steel wool. Clean with nonmetal brush or sponge.

Non-stick Coating Inner Pot

- Use a sponge to clean the inner pot.
- Use a plastic or wooden rice scoop, not metal utensils that may be damaged the surface of the inner pot.
- The non-stick coating may discolor after long use. This will not affect the non-stick coating or cleanliness of the inner pot.

SHARP


MODEL :
KS-G18TR-ST

RICE COOKER INSTRUCTION MANUAL




Please read these instructions completely before operating the unit

Parts Identification



Accessories



Specifications

Model	KS-G18TR-ST
Capacity	1.8 Liter
Power Consumption	Cook : 700W Warm : 90W
Power Supply	Ac 220-240V - 50/60Hz
Weight	2.9kg
Dimensions	271 x 293 x 285mm

How To Use



Wash the rice in a separate bowl.



Then place the washed rice in the inner pot.




Add water into the inner pot. Markings inside the inner pot show required amounts of water.
Example : If you have used two measures of rice, add water to line marked 2, and so forth.
You may adjust it depending upon the type of rice and your preference.



Be sure to wipe dry the outside of the inner pot. Then place the pan inner pot into the body and turn it slightly to the right and left until it seats properly.



Close the outer lid. Make sure to lock properly until it clicks.



Plug cord to AC outlet.
All the lamps are off, the LED shows as below:



Press the RICE COOK key, the "RICE COOK" lamp lights and the cooking process has started. The LED shows as running round as below:



If you want to have porridge, please press the PORRIDGE key, the "PORRIDGE" lamp lights and the cooking process has started. The LED shows as running round as below:



When the rice or porridge is done, the "KEEP WARM" lamp lights to show that the warmer function is working.



Steaming

The amount of water poured into the inner bowl determines the steaming time. As an approximate guide, 150 ml (1 cup) of water provides 15 minutes steaming, 300 ml (2 cups) provides 30 minutes steaming etc.

1. Pour the required quantity of water into the inner bowl.
2. Place the food to be steamed in the steaming basket and place the steaming basket on the top of the inner bowl.
3. Cover with the lid and switch on the appliance, as directed for cooking rice.
4. Once all the water has steamed away, the appliance will automatically switch to warm and the light will glow.
5. When removing the steaming basket, hold the handles using heat resistant gloves.
6. It is possible to cook rice and to steam foods simultaneously. You will need to experiment to establish appropriate amounts of water and cooking time for various combinations.